

Remote Control Guide



To Turn your TV on or off: Just press **POWER**.

Press **STB** button once, if needed, to set the remote to control the set-top box. This allows the buttons on the remote to change channels, show the guide, and control recordings.

Press **EXIT** button to close program guide or weather app.

To Change Channels:

1. Using the **GUIDE** Button: Push the **GUIDE** button, a screen will pop up with a list of channels to watch. Use the Arrow buttons above or below the **OK** button.

Once you find the channel and it's highlighted, press the **OK** button.

2. Using the Channel + or – button:

3. Just enter the channel number.